

# GHz Socket (-M) Assembly Instructions

1. Place LGA package (land side down) into the socket. NOTE: LGA orientation on target PCB is critical.
2. Place the compression plate on top of the LGA package.
3. Install the socket top assembly with the hardware provided (four 0-80 screws).
4. Turn the compression screw clockwise, until it makes contact with the compression plate.
5. Turn an additional 1/8th to 1/4th of a turn.

